

SDD-ES Series

Dehumidifying Dryer

Date: Apr. 2023

Version: Ver.A (English)



Contents

| | |
|--|-----------|
| 1. General Description | 7 |
| 1.1 Coding Principle..... | 8 |
| 1.2 Feature | 8 |
| 1.2.1 Options..... | 8 |
| 1.3 Drying Capacity..... | 11 |
| 1.4 Safety Regulations..... | 13 |
| 1.4.1 Safety Regulations for the Blowers | 13 |
| 1.4.2 Safety Signs and Labels..... | 14 |
| 1.4.3 Signs and Labels..... | 14 |
| 1.4.4 Transportation and Storage of the Machine | 15 |
| 1.5 Exemption Clause..... | 16 |
| 2. Structure Characteristics and Working Principle..... | 17 |
| 2.1 Working Principle..... | 17 |
| 2.2 Relative Humidity and Dew-point..... | 17 |
| 2.3 Why Choose SDD..... | 18 |
| 2.4 Options | 18 |
| 3. Installation Testing..... | 20 |
| 3.1 Machine Location..... | 20 |
| 3.2 Power Connectors | 20 |
| 3.3 Air pipe and material pipe connection..... | 21 |
| 3.4 Water connections | 21 |
| 3.4.1 Cooling Water Connection..... | 22 |
| 3.4.2 Condensation Drainage Pipe..... | 23 |
| 3.5 Oil Filter | 23 |
| 3.6 Plate Heat Exchanger | 24 |
| 4. Operating | 25 |
| 4.1 Operation Procedure for HMI..... | 25 |
| 4.1.1 Description of touch screen..... | 25 |
| 4.1.2 Touch panel appear error..... | 25 |
| 4.1.3 Screen operation flow Table..... | 25 |

| | |
|--|-----------|
| 4.1.4 Menu Particular | 26 |
| 4.1.4.1 System Default Screen | 26 |
| 4.1.4.2 Dehumidifying Process | 26 |
| 4.1.4.3 Password Unlock | 27 |
| 4.1.4.4 Working Modes of Regeneration Heater (Dehumidifying Function)29 | |
| 4.1.4.5 Working Modes of Material Drying | 32 |
| 4.1.4.6 Alarms Fault Records | 34 |
| 5. Trouble-shooting..... | 37 |
| 6. Maintenance and Repair | 39 |
| 6.1 The Useful Life of the Key Parts of the Product | 40 |
| 6.2 Filter | 40 |
| 6.3 Honeycomb-rotor | 41 |
| 6.3.1 What is Honeycomb-rotor..... | 41 |
| 6.3.2 Installation of the Rotor | 41 |
| 6.3.3 Honeycomb Rotor Cleaning Steps | 42 |
| 6.4 EGO..... | 43 |
| 6.5 Cooler Clear Step | 43 |
| 6.6 Maintenance Schedule | 44 |
| 6.6.1 General Machine Information | 44 |
| 6.6.2 Check After Installation | 44 |
| 6.6.3 Daily Checking | 44 |
| 6.6.4 Weekly Checking..... | 45 |
| 6.6.5 Monthly Checking..... | 45 |
| 6.6.6 Half-yearly Checking | 45 |
| 6.6.7 Yearly Checking | 45 |
| 6.6.8 3 year Checking | 45 |

Table Index

| | |
|---|----|
| Table 1-1: Drying Capacity 1 | 11 |
| Table 1-2: Drying Capacity 2 | 11 |
| Table 6-1: The useful life of the key parts of the product..... | 40 |

Picture Index

| | |
|---|----|
| Picture 1-1: Dehumidifying Dryer SDD-40U/40H-ES | 7 |
| Picture 1-2: Safety Regulations for The Blowers | 14 |
| Picture 2-1: Working Principle | 17 |
| Picture 3-1: Installation Drawing | 20 |
| Picture 3-2: Air Pipe and Material Pipe Connection Drawing..... | 21 |
| Picture 3-3: Cooling Water Connection | 22 |
| Picture 3-4: Installation Dia. of Oil Filter | 23 |
| Picture 3-5: Plate Heat Exchanger Over Figure | 24 |
| Picture 4-1: Description of Touch Screen | 25 |
| Picture 4-2: Screen Operation Flow Table..... | 26 |
| Picture 4-3: System Initial Screen..... | 26 |
| Picture 4-4: Dehumidifying Process Screen | 27 |
| Picture 4-5: Password Input Screen | 27 |
| Picture 4-6: Drying Process | 28 |
| Picture 4-7: Parameter Setting Menu Screen | 28 |
| Picture 4-8: Time Setting Screen..... | 28 |
| Picture 4-9: Parameter Setting | 29 |
| Picture 4-10: Parameter Setting Screen | 30 |
| Picture 4-11: Drying Process Screen..... | 30 |
| Picture 4-12: Dehumidify Process Screen | 30 |
| Picture 4-13: Parameter Setting Screen | 31 |
| Picture 4-14: Drying Process Screen..... | 31 |
| Picture 4-15: Dehumidify Process Screen | 32 |
| Picture 4-16: Drying Process Screen..... | 32 |
| Picture 4-17: Drying Process Screen..... | 33 |
| Picture 4-18: Recipe Setting Screen..... | 33 |
| Picture 4-19: Drying Process Screen..... | 34 |
| Picture 4-20: Drying Process Screen..... | 34 |
| Picture 4-21: Alarm Fault Records..... | 35 |
| Picture 6-1: Filter | 40 |
| Picture 6-2: Honeycomb Rotor | 41 |

| | |
|--|----|
| Picture 6-3: Installation of The Rotor | 42 |
| Picture 6-4: EGO | 43 |

1. General Description




Please read through this operation manual before using the machine to prevent damages of the machine or personal injuries.

SDD series dehumidifying dryer combine dehumidifying and drying systems into a single unit. They have many applications in processing plastic materials, such as PA, PC, PBT, PET etc. All models feature SD-H honeycomb dehumidifiers with built-in process heater and insulated drying hopper. Under ideal conditions, it can provide dehumidified dry air with a dew-point lower than -40°C .



Picture 1-1: Dehumidifying Dryer SDD-40U/40H-ES

1.1 Coding Principle



1.2 Feature

- 1) Adopt molecular sieve structure honeycomb rotor, which provides low dew-point dry air. The honeycomb rotor structure is superior to double-barrel dehumidifier that will contaminate raw material due to damaged molecular sieve.
- 2) Dehumidifying and drying function are integrated to ensure high efficiency.
- 3) Insulated drying hopper features dry air down-blowing and cyclone exhaust design. This improves drying efficiency and reduces heat loss, saving energy.
- 4) The dehumidifying section of the SDD series adopts cooler to ensure a low return air temperature and low dew-point.
- 5) Microprocessor is the standard equipment, with a temperature controlling accuracy of $\pm 1^{\circ}\text{C}$.
- 6) Equipped with weekly timer, machine can automatically operate.

1.2.1 Options

- 1) For models with energy-saving drying management, add “ES” at model end, standard equipped with HMI touch control, which can reduce 41% of total power consumption at most. Volume used per hour can be set between 40~100% of drying capacity to reduce 35%~0 of totally power consumption; Equipped with heat regenerating recycler which recycles the heat of exhausted air via plate heat exchanger and can reduce 3%~6% of total power consumption. Meanwhile, dew-point value can be set to automatically control the temperature required by regeneration, if

optional with dew-point monitor, saving 0~10% power consumption according to dew-point ranging from -40oC to 10 oC.

- 2) For models with drying heat recycler, add "HE" at the end of model code. Dehumidified low temperature air recycles the heat of hot-wet return air via plate heat exchanger, which can raise the air temperature in drying heater and reduce the power consumption of the heater, as well as reduce 0%~19% of total power consumption.
- 3) For models with polished hopper inside, add "P" at the end of the model code.
- 4) Optional air cooling function is available for SDD, which is no need of cooling water, and add "A" at the end of the model code. It is applicable for (SDD-40U/40H~SDD-230U/120H).
- 5) Upgraded to PLC & touch panel, Add "LC" at the end of the model code.
- 6) The optional built-in dew point monitor is available, which is used to monitor real-time dew point. Add "D" at the end of the model code.

All service work should be carried out by a person with technical training or corresponding professional experience. The manual contains instructions for both handling and servicing. Chapter 6, which contains service instructions intended for service engineers. Other chapters contain instructions for the daily operator.

Any modifications of the machine must be approved by SHINI in order to avoid personal injury and damage to machine. We shall not be liable for any damage caused by unauthorized change of the machine.

Our company provides excellent after-sales service. Should you have any problem during using the machine, please contact the company or the local vendor.

Shini Hotline Service:

Headquarter and Taipei factory:

Tel: + 886 (0)2 2680 9119

Shini Plastics Technologies (Dongguan), Inc.:

Tel: +86 (0)769 8331 3588

Shini Plastics Technologies (Pinghu), Inc.:

Tel: +86 (0)573 8522 5288

Shinden Precision Machinery (Chongqing), Inc.:

+86 (0)23 6431 0898

1.3 Drying Capacity

Table 1-1: Drying Capacity 1

| Material | Drying Temp. (°C) | Drying Time (hr) | Drying Capacity (kg/hr) | | | | | | |
|--------------|-------------------|------------------|-------------------------|----------|-----------|----------|------------|------------|------------|
| | | | 40U /40H | 80U /40H | 120U /80H | 160 /80H | 160U /120H | 230U /120H | 300U /200H |
| ABS | 80 | 2-3 | 16 | 18 | 27 | 27 | 35 | 105 | |
| CA | 75 | 2-3 | 12 | 15 | 22 | 22 | 29 | 90 | |
| CAB | 75 | 2-3 | 12 | 15 | 22 | 22 | 29 | 90 | |
| CP | 75 | 2-3 | 16 | 18 | 27 | 27 | 35 | 106 | |
| LCP | 150 | 4 | 11 | 13 | 40 | 40 | 27 | 80 | |
| POM | 100 | 2 | 24 | 27 | 40 | 40 | 53 | 160 | |
| PMMA | 80 | 3 | 17 | 19 | 29 | 29 | 38 | 115 | |
| IONOMER | 90 | 3-4 | 10 | 11 | 17 | 17 | 22 | 66 | |
| PA6/6.6/6.10 | 75 | 4-6 | 9 | 10 | 14 | 14 | 19 | 58 | |
| PA11 | 75 | 4-5 | 10 | 11 | 17 | 17 | 23 | 69 | |
| PA12 | 75 | 4-5 | 10 | 12 | 17 | 17 | 23 | 69 | |
| PC | 120 | 2-3 | 18 | 21 | 31 | 31 | 41 | 124 | |
| PU | 90 | 2-3 | 17 | 19 | 29 | 29 | 38 | 115 | |
| PBT | 130 | 3-4 | 13 | 15 | 23 | 23 | 31 | 93 | |
| PE | 90 | 1 | 47 | 53 | 80 | 80 | 106 | 318 | |
| PEI | 150 | 3-4 | 11 | 13 | 20 | 20 | 27 | 80 | |
| PET | 160 | 4-6 | 11 | 13 | 19 | 19 | 25 | 75 | |
| PETG | 70 | 3-4 | 11 | 13 | 20 | 20 | 27 | 80 | |
| PEN | 170 | 5 | 13 | 15 | 23 | 23 | 30 | 90 | |
| PES | 150 | 4 | 13 | 15 | 23 | 23 | 30 | 90 | |
| PPO | 110 | 1-2 | 19 | 22 | 33 | 33 | 44 | 133 | |
| PPS | 150 | 3-4 | 11 | 13 | 20 | 20 | 27 | 80 | |
| PI | 120 | 2 | 24 | 27 | 40 | 40 | 53 | 160 | |
| PP | 90 | 1 | 39 | 44 | 66 | 66 | 88 | 265 | |
| PS(GP) | 80 | 1 | 39 | 44 | 66 | 66 | 88 | 265 | |
| PSU | 120 | 3-4 | 12 | 14 | 22 | 22 | 29 | 86 | |
| PVC | 70 | 1-2 | 19 | 22 | 33 | 33 | 44 | 133 | |
| SAN(AS) | 80 | 1-2 | 19 | 22 | 33 | 33 | 44 | 133 | |
| TPE | 110 | 3 | 18 | 21 | 31 | 31 | 41 | 124 | |

- Note: 1. Please refer to above drying capacity of SCD machine, select the right model according to material usage of processing machine.
 2. Specific model selection, please consult the letter easy service personnel.

Table 1-2: Drying Capacity 2

| Material | Drying Temp. (°C) | Drying Time (hr) | Drying Capacity (kg/hr) | | | |
|----------|-------------------|------------------|-------------------------|------------|------------|-------------|
| | | | 600U /400H | 750U /400H | 900U /700H | 1200U /700H |
| ABS | 80 | 2-3 | 210 | 210 | 355 | 355 |
| CA | 75 | 2-3 | 180 | 180 | 295 | 295 |
| CAB | 75 | 2-3 | 180 | 180 | 295 | 295 |
| CP | 75 | 2-3 | 210 | 210 | 355 | 355 |
| LCP | 150 | 4 | 160 | 160 | 365 | 365 |

| | | | | |
|--------------|-----|-----|-----|------|
| POM | 100 | 2 | 320 | 530 |
| PMMA | 80 | 3 | 230 | 383 |
| IONOMER | 90 | 3-4 | 133 | 220 |
| PA6/6.6/6.10 | 75 | 4-6 | 115 | 192 |
| PA11 | 75 | 4-5 | 138 | 230 |
| PA12 | 75 | 4-5 | 138 | 230 |
| PC | 120 | 2-3 | 250 | 413 |
| PU | 90 | 2-3 | 230 | 383 |
| PBT | 130 | 3-4 | 186 | 310 |
| PE | 90 | 1 | 637 | 1062 |
| PEI | 150 | 3-4 | 160 | 265 |
| PET | 160 | 4-6 | 150 | 250 |
| PETG | 70 | 3-4 | 160 | 265 |
| PEN | 170 | 5 | 180 | 300 |
| PES | 150 | 4 | 180 | 300 |
| PPO | 110 | 1-2 | 265 | 440 |
| PPS | 150 | 3-4 | 160 | 265 |
| PI | 120 | 2 | 320 | 530 |
| PP | 90 | 1 | 530 | 885 |
| PS(GP) | 80 | 1 | 531 | 885 |
| PSU | 120 | 3-4 | 173 | 290 |
| PVC | 70 | 1-2 | 265 | 442 |
| SAN(AS) | 80 | 1-2 | 265 | 442 |
| TPE | 110 | 3 | 250 | 413 |

Note: 1. Please refer to above drying capacity of SCD machine, select the right model according to material usage of processing machine.

2. Specific model selection, please consult the letter easy service personnel.

1.4 Safety Regulations



Warning!

Electrical installation should be done by qualified technician only. Before connecting to AC Power Source, turn power switch to OFF position.

While AC power source is connected, make sure specifications and overload protection rating of the power switch are suitable and reliable.

When the machine is under care or maintenance status, turn both power switch and automatic operation switch to off.

1.4.1 Safety Regulations for the Blowers

- 1) Under normal operation, the blowers will generate high temperature. Do not touch blower's case to avoid any physical injury.
- 2) Under normal operation, the blower motor's current loading will increase or reduce according to air pressure's change accordingly. While installation, an adequate motor overload protection switch should be installed with full loading test, to ensure operating safely under full-loading to avoid motor's damage.
- 3) To avoid any block materials, dust, powder, fiber particles and water drops entering the blower, and hence cause the deficiency of its performance. This machine is well designed with air filters, so please clean up the filter with any foreign particles (recommended to clean up this filter weekly).
- 4) Clean the blowers both internal and external parts (especially for the fan cooling path), and remove surface dust if necessary. If more dusts are accumulated, it will cause deficiency for ventilation, temperature rising, vacuum power reduced, vibration increased and so it will cause machine broke down.
- 5) Ball bearing, oil seal and soundproof are belonging to consumable parts and so it has a life period and requires regular replacement. Meanwhile, blade, external case, and metallic screen etc. should be replaced regularly for best performance.
- 6) Under normal operation, if the blowers are not running smoothly or abnormal noise appeared. Please immediately shut down the machine for repair.

- 7) Don't manual discharge material inside the hopper while its not or opening cleaning door while the material is not.



Picture 1-2: Safety Regulations for The Blowers

1.4.2 Safety Signs and Labels



Danger!

High voltage danger!

This label is stuck on the electrical boxes.



Attention!

This label means that this area should be taken care!



Warning!

High temperature, take care of hands!

This label should be stick to the shell of heater.






Attention!

No need for regular inspection because all the electrical parts in the control unit are fixed tightly!

1.4.3 Signs and Labels



Hot surfaces can burn hands.

| | |
|---|---|
|  | <p>Water outlet: drainage outlet.</p> |
|  | <p>Water inlet: inlet for replenishing water and cooling water.</p> |
|  | <p>Push-and-pull switch for shut-off plate: I: Means "Pull" O: Means "Push"</p> |

1.4.4 Transportation and Storage of the Machine

Transportation

- 1) SDD series dehumidifying dryer are packed in crates or plywood cases with wooden pallet at the bottom, suitable for quick positioning by fork lift.
- 2) After unpacked, castors equipped on the machine can be used for ease of movement.
- 3) Do not rotate the machine and avoid collision with other objects during transportation to prevent improper functioning.
- 4) The structure of the machine is well-balanced, although it should also be handled with care when lifting the machine for fear of falling down.
- 5) The machine and its attached parts can be kept at a temperature from -25°C to $+55^{\circ}\text{C}$ for long distance transportation and for a short distance, it can be transported with temperature under $+70^{\circ}\text{C}$.

Storage

- 1) SDD series dehumidifying dryer should be stored indoors with temperature kept from 5°C to 40°C and humidity below 80%.
- 2) Disconnect all power supply and turn off main switch and control switch.
- 3) Keep the whole machine, especially the electrical components away from water to avoid potential troubles caused by the water.
- 4) Plastic film should be used to protect the machine from dust and rains.

Working environment

Indoors in a dry environment with max. temperature $+45^{\circ}\text{C}$ and humidity no more than 80%.

Do not use the machine

- 1) If it is with a damaged cord.
- 2) On a wet floor or when it is exposed to rain to avoid electrical shock.
- 3) If it has been dropped or damaged until it is checked or fixed by a qualified serviceman.
- 4) This equipment works normally in the environment with altitude within 3000m.
- 5) At least a clearance of 1m surrounding the equipment is required during operation. Keep this equipment away from flammable sources at least two meters.
- 6) Avoid vibration, magnetic disturbance at the operation area.

Rejected parts disposal

When the equipment has run out its life time and can not be used any more, unplug the power supply and dispose of it properly according to local code.

Fire hazard



In case of fire, CO₂ dry powder fire extinguisher should be applied.

1.5 Exemption Clause

The following statements clarify the responsibilities and regulations born by any buyer or user who purchases products and accessories from Shini (including employees and agents).


Shini is exempted from liability for any costs, fees, claims and losses caused by reasons below:

1. Any careless or man-made installations, operation and maintenances upon machines without referring to the Manual prior to machine using.
2. Any incidents beyond human reasonable controls, which include man-made vicious or deliberate damages or abnormal power, and machine faults caused by irresistible natural disasters including fire, flood, storm and earthquake.
3. Any operational actions that are not authorized by Shini upon machine, including adding or replacing accessories, dismantling, delivering or repairing.
4. Employing consumables or oil media that are not appointed by Shini.

2. Structure Characteristics and Working Principle

2.1 Working Principle

Moisture hot air from drying hopper is blown into rotor after flowing through cooler. Moisture from the air is dried by rotor and is then adsorbed by regeneration heating air. Two strands of airflow function on the rotor. And with the rotation, moisture from the air is absorbed and expelled after absorbed regeneration air to form stable low dew-point air, which is dried and heated to the drying temperature and then is blown into material barrel to closed circle to dry material.



Picture 2-1: Working Principle

2.2 Relative Humidity and Dew-point

Relative humidity: Relative air humidity means real vapor content to saturated vapor at the same temperature in percentage.

Dew point: it means that temperature when the saturation vapor begins to dew. When the relative humidity is 100%, the ambient temperature is the dew point temperature. The more lower of dew point temperature (than the ambient temperature) is, the more less possible to dew, that also means the more drier the air is. The dew point will not be influenced by temperature, but influenced by pressure.

2.3 Why Choose SDD

For these quality deficiencies as bubble, crazing, cracking, poor transparency are due to insufficient drying of plastic materials before molding, and the engineering plastics such as: PC, PA, PBT, PET, Nylon, etc. The hygroscopic materials used in the plastics industry such as PC, PA, PBT, PET, Nylon, etc. cannot be dried effectively by conventional hot air drying systems because the moisture enters inside the particles. According to suggestion of the manufacturer, the plastic materials can be completely dried by drying air with dew-point temperature $\leq -20^{\circ}\text{C}$. However, the SCD sufficiently dehumidifies and dries the air inside the closed-loop system, and the dry air eliminates the moisture fast and completely as to reach the drying and dehumidifying effect.

2.4 Options

- Built-in type, which means that dew-point monitor is installed on the machine, is convenient to monitor dew-point temperature. Add "D" at the end of the model code.
- Portable type, which means that dew-point monitor is separate from the machine, is convenient to test dew-point temperature of different machines. Add "PD" at the end of the model code.



Dew-point Monitor (portable)

- For models optional with dew-point control, add "DC" at model behind. "ES" by setting if dew-point value to control the regeneration required temperature automatically and lowers power consumption of the regenerative heater; According to $-40^{\circ}\text{C}\sim+10^{\circ}\text{C}$ of dew-point value, the total power consumption can save 0~10%.
- For models with energy-saving drying management, add "ES" at model behind, standard equipped with HMI touch control, which can save up to

41% of total power consumption. Volume used per hour is settable between 40~100% as drying capacity to save the totally power consumption of 35%~0; Standard equipped with heat regenerative recycler which recycles the regeneration air exhausted heat via plate heat exchanger and can save 3%~6% of total power consumption.

- For models optional with drying heat recycler, add "HE" at model behind. Dehumidified low temperature air via plate heat exchanger to recycle the heat of hot-wet return air, which can higher the air temperature in drying heater and lower the power consumption of the heater, the total power consumption can save 0%~19%.
- For models with hopper polished inside, at "P" at the end of the mode code.

3. Installation Testing

This series of models only could be applied in working environment with good ventilation.

3.1 Machine Location



Picture 3-1: Installation Drawing

Installation Notice:


- 1) The machine can only be installed in the vertical position, make sure there's no pipeline, fixed structure and other object which may obstruct machine installation or cause items, human injuries above the selected location and adjacent areas.
- 2) For easy maintenance, leaving 1m space around machine is suggested. Keep machine 2m away from the inflammable materials.
- 3) The machine must be placed on the ground level to ensure balance state, and to remove the accumulated condensing water. If machine is need to install on a higher level (scaffolding or interlayer), it should make sure that the structure and size could withstand the machine.

3.2 Power Connectors

- 1) Make sure voltage and frequency of the power source comply with those indicated on the manufacturer nameplate, which is attached to the machine.

- 2) Power cable and earth connections should conform to your local regulations.
- 3) Use independent power cable and ON/OFF switch. The cable's size should not smaller than those wired in the electrical requirement of control panel.
- 4) The power cable connection terminals should be tightened securely.
- 5) The machine requires a 3-phase 4-wire power source, connect the power lead (L1, L2, L3) to the live wires, and the earth (PE) to the ground.
- 6) Power supply requirements:
 Main power voltage: $\pm 5\%$
 Main power frequency: $\pm 5\%$
- 7) **Refer to the electrical wiring diagram to complete the electrical installation.**


3.3 Air pipe and material pipe connection




Picture 3-2: Air Pipe and Material Pipe Connection Drawing

3.4 Water connections


The cooling water pressure is 3~5bar and the cooling water temperature should be 10~30°C.





Water inlet: inlet for replenishing water and cooling water.

Cooling water needs to be connected the before operation. The water port is at the back of the machine.



Picture 3-3: Cooling Water Connection

3.4.1 Cooling Water Connection

Connect through the cooling water before machine operation. For the efficiency, please follow below suggestions:

- 1) For easy maintenance and safety, install the ball valve at cooling water inlet and outlet.
- 2) Water pipe diameter should not less than the diameter of cooling water inlet and outlet.
- 3) For water quality, it needs to sediment or filter the water before it gets into the pipe, to prevent the deposits accumulated on pipeline of cooler and performance degradation.

| Cooling Water Specifications | | | |
|------------------------------|-------------------------------------|-------|-------------------------------------|
| Model | Flowrate of Cooling Water (L/min) | Model | Flowrate of cooling Water (L/min) |
| 30H | 4 | 400H | 50 |
| 40H | 5 | 500H | 60 |
| 50H | 6 | 700H | 80 |
| 80H | 10 | 1000H | 120 |
| 120H | 15 | 1500H | 180 |
| 150H | 20 | 2000H | 240 |
| 200H | 30 | 3000H | 360 |

| | | | |
|------|----|-------|-----|
| 300H | 40 | 4000H | 480 |
|------|----|-------|-----|


Note: 1. Difference in temperature: 5°C
 2. Cooling water pressure: 3~5Kgf/cm²

3.4.2 Condensation Drainage Pipe

During normal operation, it will generate condensation water. Connect the water pipe at drainage outlet to remove the condensation water is necessary.

- 1) Drainage pipe inner diameter should not less than the diameter of drainage outlet.
- 2) Drainage pipe should be long enough to approach the drainage channel, and be the hose. Be careful not to press or bend the pipe for smooth water flow (Use the rigid pipe if there's need to press or bend the hose).
- 3) As condensation water drainage is in terms of gravity, make sure the drainage outlet is above the pipe. Otherwise the water can't be drained out and will flow back to the machine.

3.5 Oil Filter




Picture 3-4: Installation Dia. of Oil Filter

Oil Filter Installation Steps:

- 1) Screw the oil filter on the top plate of the honeycomb dehumidifier.
- 2) Connect 1 and 2 with a heat-resistant duct and fixed both the ends with stainless steel tube.

- 3) Connect 3 and 4 with a heat-resistant duct and fixed both the ends with stainless steel tube.
- 4) Connect 5 and 6 with a heat-resistant duct and fixed both the ends with stainless steel tube.

3.6 Plate Heat Exchanger



Picture 3-5: Plate Heat Exchanger Over Figure

Each part is connected by heat-resistant air pipes and fixed by stainless steel pipes as shown in the diagram.

4. Operating

4.1 Operation Procedure for HMI

- 1) Do not use keen-edged object instead of hands to operate the touch screen, and prevent violent collision of it.
- 2) In a dry environment, static electricity may accumulate on the touch screen. Use a metal wire to discharge it before operating.
- 3) Use alcohol or eleoptene to wipe off the pollutants on the screen. Other solvent may cause the color of the screen to fade out.
- 4) Do not tear down any parts of the touch screen or take away any PCBs attached to it.

4.1.1 Description of touch screen



Picture 4-1: Description of Touch Screen

A: Display


B: Touch panel

4.1.2 Touch panel appear error

Table 4-1: Touch Panel Information

| LED indicator light | State |
|---------------------|-------------------------|
| Green (light) | Work well |
| Orange (light) | Backlight lamp burning |
| Orange (shine) | During software startup |
| Red (light) | Power status |
| No shine | Power break off |

4.1.3 Screen operation flow Table




Picture 4-2: Screen Operation Flow Table

4.1.4 Menu Particular


4.1.4.1 System Default Screen

When the system is connected with power source, the initial default screen will display as shown below. By touching the button of "English" or "Chinese" to select either English or Chinese language in order to login "Drying Process" screen.



Picture 4-3: System Initial Screen


4.1.4.2 Dehumidifying Process




Picture 4-4: Dehumidifying Process Screen


4.1.4.3 Password Unlock

- 1) Input user name: shini
- 2) Input password: 3588
- 3) Press “Unlock”
- 4) Press “Return”, finish unlocking.




Picture 4-5: Password Input Screen

Press  in dehumidifying control screen to enter drying monitor screen.




Picture 4-6: Drying Process

Press parameter setting button  in dehumidifying process screen to enter parameter settings menu screen.




Picture 4-7: Parameter Setting Menu Screen

When using weekly-timer mode, press weekly-timer function button  to enter weekly-timer screen and set one-week timer function.



Picture 4-8: Time Setting Screen

Press parameter settings button  to enter parameter setting screen.



Picture 4-9: Parameter Setting

Rotor alarm time: Used to detect whether honeycomb rotor is rotating. Factory setting is 10min.

Blower stop delay time: When turning off the machine, blower's stop will be delayed to cool down the heat inside heater box to prevent the temperature inside the box keeps rising after machine's turning off. Factory setting is 3min.

Overheat alarm: Used for protection by preventing the system temperature rise beyond the temperature range. Factory setting is 15°C.


Cooling water temperature setting: Cooling water is used when the temperature is above the set temperature. Factory setting is 60°C.

4.1.4.4 Working Modes of Regeneration Heater (Dehumidifying Function)

A. Regeneration Mode


Setting Steps:

- 1) Enter parameter setting screen, press mode button, choose regeneration mode.



Picture 4-10: Parameter Setting Screen

- 2) Enter drying control screen, set material drying temperature and air volume.



Picture 4-11: Drying Process Screen

- 3) Set regeneration temperature (180°C)




Picture 4-12: Dehumidify Process Screen

4) Press button, machine will start-up..

Note: In this mode, regeneration temperature and drying air volume of the machine are constant. Machine will operate under a setting drying temperature, air volume and regeneration temperature.


B. Energy saving mode

1) Enter parameter setting screen, press , choose energy saving mode.



Picture 4-13: Parameter Setting Screen

2) Enter drying control screen, set material drying temperature and air volume.




Picture 4-14: Drying Process Screen

3) Set dew-point temperature




Picture 4-15: Dehumidify Process Screen

- 4) Press  button, machine will start up.

Note: In this mode, regeneration temperature (dehumidifying temperature) will be adjusted according to the change of dew-point temperature to saving energy

4.1.4.5 Working Modes of Material Drying

A. Normal Drying Mode




Picture 4-16: Drying Process Screen

Note: In this mode, only drying temperature and air volume need to be set. Machine will dry the material under a set temperature and air volume.


B. Activate Recipe-Drying Mode

1) Press **OFF** button,




Picture 4-17: Drying Process Screen

2) Set Parameter of The Recipe



Picture 4-18: Recipe Setting Screen

3) Drying Process screen



Picture 4-19: Drying Process Screen

Note: In this mode, drying air volume will change according to the throughput set in the recipe.

C. Using return-air's temperature control mode

- 1) Press  to make it run.



Picture 4-20: Drying Process Screen

Set drying temperature and return-air temperature of the material as picture above.

Note: In this mode, drying air volume will adjust according to return-air's temperature to achieve energy saved controlling.

4.1.4.6 Alarms Fault Records

Touch " Alarm Fault Records " button on the right of "Drying Process" screen or "Conveying Process" screen to enter into Alarm Fault Records screen. The screen

is shown as below:



Picture 4-21: Alarm Fault Records

1. When alarm fault records cover more than displaying space, touch "Up" or "Down" keys to read more records.
2. According to the alarm information, the operator could get the troubleshooting information from the instruction book.
3. Press "EXIT" button to exit from this screen.

Table 4-2: Alarm Information List

| Alert message | Range | Results | Possible causes |
|-------------------------------|-----------------|--|--|
| Anti-phase | SCD,SDD SD-H | System cannot operate, and the visible alarm is flickering. | Low voltage, anti-phase |
| Process blower overload. | SCD,SDD SD-H | Dehumidifier does not work and the visible alarm is flickering. | Incorrect motor overload setting, or motor burns out. |
| Regenerating blower overload. | SCD,SDD SD-H | Dehumidifier does not work and red alert light is flickering. | Incorrect motor overload setting, or motor burns out. |
| Conveying blower overload. | SCD | Material conveying stops and the visible alarm is flickering. | Incorrect motor overload setting, or motor burns out. |
| No.1 receiver suction problem | SCD | No.1 receiver stop suction function and the visible alarm is flickering. | Storage tank lacks material, suction probe problem, parameter wrongly setting, shut-off valve damaged. |
| No.2 receiver suction problem | SCD | No.2 receiver stop suction function and the visible alarm is flickering. | Drying hopper lacks material, suction box problem, parameter wrongly set, shut-off valve damaged. |
| No.3 receiver suction problem | SCD | No.3 receiver stop suction function and the visible alarm is flickering. | Drying hopper lacks material, suction box problem, parameter wrongly set, shut-off valve damaged |
| Process temperature overheat | SDD,SCD | Dehumidifier does not work and the visible alarm is flickering. | Temperature control parameter wrongly setup, touching pad is malfunction, process heating problem. |
| Regenerating temp.overheat | SCD,SDD SD-H | Alarm display on screen | 1. Temperature control parameter set envi 2. Contactor fail |

| | | | |
|---|-----------------|--|---|
| | | | 3. Thermocouple fail |
| Temp. overheat | SCD,SDD SD-H | Message display screen | No water supply or high water temperature. |
| Process temp. Thermople broken | SDD,SCD | Dehumidifier does not work and the visible alarm is flickering. | Thermocouple disconnected or bad contact. |
| Regenerating temp. Thermocouple broken | SCD,SDD SD-H | Dehumidifier does not work and the visible alarm is flickering. | Thermocouple disconnected or bad contact. |
| Rotor is not working | SCD,SDD SD-H | Dehumidifier stop and the visible alarm is flickering. | Rotor driving motor burnt, belt broken, micro switch fail, or incorrect rotor speed monitoring parameter setting. |
| PLC is not under operation mode | SCD,SDD SD-H | System stops. | PLC work mode is not in RUN mode. |

- Note: 1) Overload Relay reset: Open control box, press "RESET" button on the corresponding overload relay.
 2) Rotor Failure Alarm reset: Turn off the Drying Switch and then turn it "ON" again.
 3) Over Temperature Alarm reset: Turn off the Drying Switch and then turn it "ON" again after the temperature drops down.

5. Trouble-shooting

| Troubles | Possible causes | Solutions |
|---|---|--|
| Main power indicator does not light after turn on main power switch. | 1. Does not connect through power supply. | 1. Connect through power supply. |
| | 2. Main power switch breakdown. | 2. Replace main power switch. |
| | 3. Problems of electrical wires. | 3. Check electrical wires. |
| | 4. Fuse of control circuit melted. | 4. Check electrical wires and replace fuse. |
| | 5. Transformer problems. | 5. Replace the transformer. |
| E-02 is shown at PV, buzzer sounds and machine stops. | 1. Voltage of power supply is too low. | 1. Check the power supply. |
| | 2. Phase failure | 2. Check the power supply. |
| | 3. Phase frequency mistakes. | 3. Exchange the connection of two of the electrical wires. |
| Overload alarm of blower lit up, buzzer sounds and machine stops. | 1. Abnormal fluctuation of voltage. | 1. Check power supply. |
| | 2. Blower being stalled. | 2. Check the blower. |
| | 3. Failures of blower motor. | 3. Check the motor. |
| | 4. Setting current of overload relay (F1) is too low. | 4. Set the current of overload relay 1.1 times of rated current of the motor. Reset overload relay: Press down the blue button on the relay after 1 minutes. |
| Heater overheat alarm is lit up, and the buzzer sounds and machine stops working. | 1. Temperature setting mistakes. | 1. Correctly set the parameters of temp.controller. |
| | 2. Temp. measuring mistakes. | 2. Replace thermocouple. |
| | 3. Contactor failure: Process heater. | 3. Replace the contactor. |
| E-04 is shown at PV, buzzer sounds and machine stops | 1. Heater contactor seized up. | 1. Check or replace the heater contactor. |
| | 2. EGO parameter setting wrong. | 2. Set EGO parameter correctly. |
| | 3. EGO fault. | 3. Replace EGO. |
| | 4. Circuit fault. | 4. Check circuit. |
| E-09 is shown at PV, buzzer sounds and machine stops | 1. Problems of rotor motor. | 1. Check or replace the motor. |
| | 2. Rotor belt broken. | 2. Replace the belt. |
| | 3. Problems of electrical circuit. | 3. Check the electrical circuit. |
| | 4. Micro switch of the rotor failures. | 4. Replace. |
| | 5. Parameter mistakes of timer for control of rotor. | 5. Reset the timer. (Set time should be bigger than rotor rotating time in one turn and plus 1 minute.) |
| Abnormal temp. fluctuations. | 1. Too short of time since start of the machine. | 1. Wait for a while. |
| | 2. Improper parameters for temp. controller. | 2. Check the parameters of temp. Controller. |
| Heater temp. can not rise up. | 1. Temp. Setting is too high. | 1. Set heater temp. under 180℃. |
| | 2. Contactor of heater is bad. | 2. Replace contactor. |
| | 3. Heater is damaged. | 3. Replace pipe heater. |
| | 4. Problems of thermocouple. | 4. Replace thermocouple. |
| | 5. Parameter of temp. controller is set to STOP. | 5. Set temp. controller under working mode. |
| | 6. Temp. controller output problems. | 6. Replace or repair temp. controller. |
| Breaker tripping off when connects with power supply. | 1. Short circuits of main circuit. | 1. Check the circuit. |
| | 2. Short circuit of transformer. | 2. Replace the breaker. |
| | 3. Problems of breaker. | 3. Replace the breaker. |

| Troubles | Possible causes | Solutions |
|---|-----------------------------|----------------------------|
| Circuit breaker trips right after system switch on. | 1. Blower short circuits | 4. Please check the blower |
| | 2. Problems of the breaker. | 5. Replace the breaker. |

6. Maintenance and Repair

Check the accuracy of the temperature controller.
Period: Daily.

Check whether the dew point is normal. (when dew-point monitor is installed on the machine) Period: Daily.

Check whether the contactor is normal.
Period: Weekly.

Replace the PC board.
Period: every 3 years.

Replace the no fuse switch. Period: when damage occurs.

Check whether the air pipeline.
Period: Weekly.


The maintenance and repair of honeycomb
a. make sure the gear motor and the synchromesh gear have no damage.
b. clean the honeycomb.
Period: Semiyearly.

Replace the heaters when breaking down.

Check the over temperature protector (stop heating when heater temperature reaches the set value of over temperature protector.)


Clean the cooler.
Period: Semiyearly.

Clean the dust-proof screen. Period: Monthly



Filter cleaning
Period: Daily.

Cleaning steps: unscrew the plum flower nut, demount the filter cover, unscrew the butterfly nut and take out the filter. Use compressed air to blow off the dust from inside out. Reinstall it after cleaning.
Notice: do not fall any impurities into the filter.



Clean the Blower

- a. Blow off the dust inside and outside the blower. Period: Monthly.
- b. Replace the bearing, grease seal and muffler according to the operating environment.
- c. Replace the blades, shell and metal mesh according to the operating environment.

6.1 The Useful Life of the Key Parts of the Product

Table 6-1: The useful life of the key parts of the product

| Name of the parts | Useful life |
|-------------------|--------------------|
| Blower | Above 5 years |
| Process heater | Above 1 year |
| Regen. heater | Above 1 year |
| Contactora | Above 2000,000 act |
| Honeycomb | 5 years |
| Filter | 1 year |

6.2 Filter

Please periodically clean the dust on the air filters, once per week.

Cleaning steps:

- 1) Take out the air filter carefully.
- 2) Blow off the dust on the air filter screen and the cover with pressure air.
- 3) Wipe off the barrel wall of air filter with dishcloth.
- 4) After cleaning, place all parts in reversed order carefully.
- 5) Please ensure that the filter is well seal with metal frame.



Picture 6-1: Filter

Note: Don't let foreign object enter into the barrel, when taking out the air filter.

6.3 Honeycomb-rotor

6.3.1 What is Honeycomb-rotor

The main body of the honeycomb-rotor is a honeycomb, made by ceramic fibre and organic additives, sintered under high temperature with molecular sieve and silica gel, to be strongly bonded together and form a solid and hard surface. Not like common molecular sieve, which will produce dusts and fines to pollute raw materials when aging or become saturated requiring regular replacement, the moisture of return air is quickly absorbed by numerous tunnels before coming out of the rotor to form low dew-point air. At the same time, regenerating blower takes dry air into the honeycomb-rotor from an opposite direction to regenerate the rotor.



Picture 6-2: Honeycomb Rotor

6.3.2 Installation of the Rotor

- 1) The upper and lower lid of honey-comb should install Teflon gasket (Fig. 1).
- 2) Use 4 screws to fix the rotor base on the machine frame firmly, and then install the shaft accordingly (Fig. 2).
- 3) Install the garmotor and transmission gear (Fig. 4).
- 4) Install and fix the main support screws (Fig. 3).
- 5) Fit the transmission belt in proper position (Fig. 6).
- 6) Install the honeycomb-rotor (Fig. 9) and transmission belt (Fig. 12).
- 7) Fix the rotor top cover (Fig. 8).
- 8) Fit all springs and tighten the screws (Fig. 7).

- 9) Install both the transmission belt (Fig. 13) and belt tension regulator (Fig. 14).
- 10) Install micro-switch and fixed board firmly (Fig. 10).



Picture 6-3: Installation of The Rotor

6.3.3 Honeycomb Rotor Cleaning Steps

1. Use a vacuum-cleaner with brush to suck up the dust on rotor surface.
2. Blow off the dust in the rotor channels with compressed air.
3. If there is dirt sticking to the channel walls inside the rotor, cleaning steps are as follows:
 - a. Saturate the rotor by blowing humid air (higher than 60%RH) through the rotor without having regeneration circuit on. This can be done by just turning the regeneration heater off and still have the process blower running if process air has high humidity. If the process air is too dry try to put a humidifier in the air stream. Do this for one hour.
 - b. According to the character of the dirt, sink the rotor into water with cleaning agent in it (PH value 3~2 liquid is applied to silica gel, PH value 7~10 applied to molecular valve). Greasy dirt should be put into a detergent solution with

xylylene. 15 minutes cleaning is suggested.

- c. Take the rotor out of the liquid and let it rest with the channels vertically for 5 minutes so the liquid can run out.
- d. Blow off the residual liquid in the channels with compressed air.
- e. Put the rotor back into the dehumidifier and run the unit with regeneration circuit (the regeneration temperature between 50°C and 60°C) on for at least one hour.



Note!

1. Note that in the dry air and wet air outlets, there will be high concentrations liquid out for some time. If a solvent has been used, there will be a residual smell for several days.
2. For some dirt which is greasy and sticky in the rotor, 100% elimination is impossible. The only one thing you can do is to replace the rotor for the cleaned rotor performance can only be recovered partly.

6.4 EGO



The EGO value has been setting before out factory, Don't modify it.



Picture 6-4: EGO

6.5 Cooler Clear Step

- 1) Disassemble the cooler's pipe and screw, and remove the cooler out of the chiller.
- 2) Release the fixed screw on the upper and lower cover of cooler and disassemble the cover.
- 3) Use brushes, compressed air or low pressure water to clean the dust and sundries on the cooler fan and copper pipe. Notes: water residue on the cooler fan and copper pipe should be dried with compressed air.

- 4) Make the cooler's upper and lower cover junction clean enough and smear the silica gel then fixed the covers with screws.
- 5) Put the cooler on the air at least 4 hours to make the silica gel drying enough then fix the cooler on the chiller and connect all pipes.

6.6 Maintenance Schedule

6.6.1 General Machine Information

Model _____ SN _____ Manufacture date _____

Voltage _____ Φ _____ V Frequency _____ Hz Power _____ kW

6.6.2 Check After Installation

- Check that the conveying pipes are tightly locked.
- Check that the material clearance door is firmly closed.
- Check that the conveying pipes are correctly connected.
- Check if there are damages of honeycomb-rotor.

Electrical Installatio

- Voltage: _____ V _____ Hz
- Fuse melt current: 1 Phase _____ A 3 Phases _____ A
- Check the phase frequency of power supply.
- Check rotating direction of regenerating motor.
- Check rotating direction of conveying blower fans.

Check air supply of compressor

- Compressed air pressure _____ bar
- Air flow _____ L/nun
- Check if the compressed air purified or not.

6.6.3 Daily Checking

- Check the switch of the machine.
- Check auto start-up of the machine.
- Check the temperature controller.
- Clean the filter.
- Check whether overheat protection is normal.

- Check whether dew-point is normal.

6.6.4 Weekly Checking

- Check all the electrical wires.
- Check if there are loose electrical connections.
- Check and maintain compressed-air filter and regulator.
- Check solenoid valve.
- Check motor overload relay and anti-phase function.
- Check whether air pipe is shed, leaked and loose.

6.6.5 Monthly Checking

- Check if transmission belt is loose or not.
- Check the status of gear motor performance.
- Check if there is leakage in the rotor.

6.6.6 Half-yearly Checking

- Check if there are damages of conveying pipe.
- Check the pipe heater.
- Check regenerating/conveying blower and fans of the motor.
- Check whether honey-comb rotor belt is damaged.
- Clean the cooler.

6.6.7 Yearly Checking

- Check whether the contactor is normal ¹.

6.6.8 3 year Checking

- PC board renewal.
- No fuse breaker renewal.

Note: 1. Manufacturer laboratory data for AC contactor is two million times in life. we suggest service life for one million four hundred thousand times, if work eight hours per day, recommended replacing frequency is 1.5 years, if work day and night, replacement is suggested to be done every six months.