


版本	Ver.B
Mark	Before modification
	After modification
	Modify date
	Checked by
	Proofread by
	Designer
	Drawer
	Version
	Approved by
	Date
	20170803

Title		PNL		Drawing NO.	
Electrical Diagram		CB/SV/PNL-CE-400V-A-1		Scale	
				Standard	
				Voltage	
				Frequency	
				Page 1	
				Totally 2	
				Pages	
				400V	
				50HZ	





1 2 3 4 5 6 7 8



Frequency converter(Optional)

Note: when function of frequency conversion and speed adjustment is not chosen, U1, V1 and W1 should be directly connected to the thermomagnet circuit breaker Q1.

版本 Ver.B

Drawing NO.		Scale		Page	
CB/SV/PNL-CE-230V-A-1		Standard		1	
Title		Standard		Totally	
PNL Electrical Diagram		Voltage		2	
Version		Frequency		Pages	
A		230V		8	
Approved by		Frequency		230V	
Date		Frequency		50HZ	
20170803		Frequency		50HZ	
Date		Frequency		50HZ	
20170803		Frequency		50HZ	
Date		Frequency		50HZ	
20170803		Frequency		50HZ	



