


1. Assembly Drawing (SCR-160U)



Remarks: Please refer to material list 2 for specific explanation of the Arabic numbers in parts drawing.



2. Parts List (SCR-160U)


| No. | Name | Part No. | No. | Name | Part No. |
|-----|--------------------------------|---------------|-----|---------------------------|---------------|
| 1 | Blower* | BM30055000060 | 8 | Filter* | YR50203000000 |
| 2 | Rotary valve SRV-4S | CG24000400150 | 9 | Filter barrel fastener * | YR10708000000 |
| 3 | Rack metal plate | BK11016000220 | 10 | Filter bag | BP82184500000 |
| 4 | Pipe heater (12kW)* | BH70161200050 | 11 | Manual butterfly valve 3" | YW59030000100 |
| 5 | Rotory level switch* | YE15000200000 | 12 | Mixing shaft assembly | - |
| 6 | 3" heat-resistant air pipe* | YW72033600100 | 13 | Mixing gear motor* | YM10773700000 |
| 7 | 3.5"stainless steel pipe clamp | YW02003500000 | | | |

* means possible broken parts.

** means easy broken part. and spare backup is suggested.



3. Mixing Shaft Assembly (SCR-160U)



Remarks: Please refer to material list 4 for specific explanation of the Arabic numbers in parts drawing.


4. Parts List of Mixing Shaft Assembly (SCR-160U)

| No. | Name | Part No. | No. | Name | Part No. |
|-----|----------------------|---------------|-----|------------------------|---------------|
| 1 | Cap nut | BH10162400010 | 9 | Upper mixing blade 3 | BH10016001710 |
| 2 | Lower mixing blade 3 | BH10016000810 | 10 | Upper sleeve | BH10016005710 |
| 3 | Lower mixing blade 2 | BH10016000710 | 11 | Upper mixing blade 2 | BH10016002110 |
| 4 | Lower sleeve | BH45440000010 | 12 | Flat key of gear motor | BH11167100010 |
| 5 | Lower mixing blade 1 | BH10016000610 | 13 | Mixing shaft | BH10016002010 |
| 6 | Bracket | BH10016001610 | 14 | Bearing cover | BH10016000110 |
| 7 | Upper mixing blade 1 | BH10016001910 | 15 | Bearing 6206ZZC3E* | YW30620600000 |
| 8 | Upper mixing blade 4 | BH10016005610 | 16 | Top sleeve | BH10016001810 |

* means possible broken parts. ** means easy broken part. and spare backup is suggested.



5. Assembly Drawing (SCR-450U/900U)



Remarks: Please refer to material list 6 for specific explanation of the Arabic numbers in parts drawing.



6. Parts List (SCR-450U/900U)


| No. | Name | Part No. | | |
|-----|-------------------------------|----------------|---------------|--|
| | Name | SCR-450U | SCR-900U | |
| 1 | Rotary valve | CG24000400150 | CG24000500150 | |
| 2 | Mixing shaft assembly | - | - | |
| 3 | Rotory level switch * | YE15000200000 | YE15000200000 | |
| 4 | Rack metal plate | BK11045000820 | BK11090000520 | |
| 5 | Mixing gear motor * | YM50538200800 | YM50638200200 | |
| 6 | Pipe heater* | BH70045000850 | BH70090000950 | |
| 7 | Stainless steel pipe clamp | YW0250120000s0 | YW02006500000 | |
| 8 | Heat-resistant air pipe* | YW72060400000 | YW72053600000 | |
| 9 | Filter cloth bag | BP82206500044 | BP82256500044 | |
| 10 | Blower* | BM30224000050 | BM3030000610 | |
| 11 | Filter* | YR50241400100 | YR50275700000 | |
| 12 | Filter barrel fastener * | YR10026000000 | YR10034000000 | |
| 13 | Six hole sight-glass assembly | BH90000600050 | BH90000600050 | |

* means possible broken parts.

 ** means easy broken part. and spare backup is suggested.



7. Assembly Drawing (SCR-1600U)



Remarks: Please refer to material list 8 for specific explanation of the Arabic numbers in parts drawing.


8. Parts List (SCR-1600U)

| No. | Name | Part No. | No. | Name | Part No. |
|-----|-----------------------|---------------|-----|----------------------------|---------------|
| 1 | Rotary valve | CG24000500150 | 6 | Pipe heater * | BH70160000850 |
| 2 | Mixing shaft assembly | - | 7 | Stainless steel pipe clamp | YW02008500000 |
| 3 | Rotory level switch * | YE15000200000 | 8 | Heat-resistant air pipe * | YW72080400000 |
| 4 | Rack metal plate | BK11160006220 | 9 | Filter cloth bag | BP82851200244 |
| 5 | Mixing gear motor * | YM50738200000 | 10 | Blower* | YM30190500000 |

* means possible broken parts. ** means easy broken part. and spare backup is suggested.



9. Assembly Drawing (SCR-2500U)



Remarks: Please refer to material list 10 for specific explanation of the Arabic numbers in parts drawing.



10. Parts List (SCR-2500U)

| No. | Name | Part No. | No. | Name | Part No. |
|-----|---------------------------------|---------------|-----|---------------------------------|---------------|
| 1 | Filter* | YR50277500000 | 11 | Big star nut assembly | YW09101500000 |
| 2 | Filter barrel fastener* | YR10034000000 | 12 | Pipe heater* | BH7080000850 |
| 3 | Filter cloth bag | BP82281200044 | 13 | Stainless steel pipe clamp 8.5" | YW02008500000 |
| 4 | Rack metal plate | BK11250000020 | 14 | Heat-resistant air pipe 8"* | YW72080400000 |
| 5 | Rotary valve SRV-5S | CG24000500150 | 15 | Exhaust fan | YM60121200400 |
| 6 | Mixer assembly | - | 16 | Control box | BH39250000250 |
| 7 | Gear motor* | YM50838200000 | 17 | Drying blower* | YM30001500000 |
| 8 | Tempered glass** | YW70000100000 | 18 | Castor with brake 3" | YW03000300000 |
| 9 | Sight glass six-hole fastener** | YR40000600000 | 19 | Movable castor 3" | YW03000300200 |
| 10 | Sight glass iron sheet | YW09000600000 | | | |

* means possible broken parts. ** means easy broken part. and spare backup is suggested.