

SEC-H

Energy-saving Intelligent Drying Control System

Date: Aug., 2023

Version:Ver. A



Contents

1. General Description	4
1.1 Coding Principle.....	5
1.2 Feature	5
1.3 Safety Regulations.....	7
1.3.1 Safety Signs and Labels.....	7
1.3.2 Sign and Labels.....	7
1.4 Exemption Clause.....	8
2. Structure Characteristics and Working Principle	9
2.1 Working Principle	9
3. Installation and Debugging.....	10
3.1 Power Connection.....	10
4. Operation Guide	11
4.1 Control Panel	11
4.2 Common Interface	12
4.2.1 Startup delay screen.....	12
4.2.2 Home screen	12
4.2.3 Fault screen.....	14
4.2.4 Delayed shutdown and standby interface.....	15
4.3 User Menu	16
4.4 User Parameter Operations	16
4.5 Parameter Table	17
4.5.1 User Parameter Setting Table	17
4.5.2 Recipe list.....	20
4.5.3 Trouble Table	21
5. Maintenance and Repair	23
5.1 Blower.....	23

Table Index

Table 1-1: Label Description	7
Table4-1: Control Panel.....	11
Table4-2: User Menu Parameter Table.....	16
Table4-3: User Parameter Setting Table	17

Table4-4: Recipe List	20
Table4-5: Trouble Table.....	21

Picture Index

Picture 1-1: Energy-saving Intelligent Drying Control SystemSEC-500H.....	4
Picture 2-1 Working principle	9
Picture 4-1: Control Panel	11
Picture 4-2: Startup delay screen.....	12
Picture 4-3: Home screen	13
Picture 4-4: Fault screen.....	15
Picture 4-5: Standby interface.....	15

1. General Description




Please read through this operation manual before using the machine to prevent damages of the machine or personal injuries.

The energy-saving intelligent drying control system SEC-H can be implemented and modified on most hopper dryers. Remove the original control system of the hopper dryer and replace it with the Shini energy-saving intelligent drying control system, which can save 30%~80% energy consumption according to different blower airflows and environments.



Picture 1-1: Energy-saving Intelligent Drying Control System SEC-500H

1.1 Coding Principle



1.2 Feature

- 1) Features microcomputer PID controller, LCD screen.
- 2) 28 default preprograms material receipt, and simply select materials as required. The system can automatically set the drying and exhaust air temperatures for easy operation.
- 3) It has a self-adaption function and simply sets the drying temperature; the control system will match the exhaust air temperature. It is widely applicable.
- 4) One-week timer and intermittent running function
- 5) With heat insulation and anti-over-drying function, the control system can automatically reduce the drying temperature and airflow when it stops material throughput to prevent material from excessive drying;
- 6) Overheat, low-temperature alarm, RS485 interface functions.
- 7) Standard input for thermal overload protector of the heater or blower.
- 8) ***This machine can adjust the drying airflow and temperature automatically based on actual material consumption to achieve energy-saving and excessive drying prevention purpose. According to different material types and outputs, it can save up to 30% ~80% energy consumption.***

All service work should be carried out by a person with technical training or corresponding professional experience. The manual contains instructions for both handling and servicing. Chapter 5, which contains service instructions intended for service engineers. Other chapters contain instructions for the daily operator.

Any modifications of the machine must be approved by SHINI in order to avoid personal injury and damage to machine. We shall not be liable for any damage caused by unauthorized change of the machine.

Our company provides excellent after-sales service. Should you have any problem during using the machine, please contact the company or the local vendor.

Shini Hotline Service:

Headquarter and Taipei factory:

Tel: + 886 (0)2 2680 9119

Shini Plastics Technologies (Dongguan), Inc.:

Tel: +86 (0)769 8331 3588

Shini Plastics Technologies (Pinghu), Inc.:

Tel: +86 (0)573 8522 5288

Shinden Precision Machinery (Chongqing), Inc.:

+86 (0)23 6431 0898

1.3 Safety Regulations



Note:

Electrical installation should be done by qualified electrician only.

Before connecting to the AC power supply, make sure whether the power switch specifications and the rated current for load protection are appropriate and safe, and please be noted to set the main power switch to the "OFF" state before power connection. Before machine repairing and maintaining, turn off the power switch and automatic switch first.

1.3.1 Safety Signs and Labels



Danger!

High pressure!

It is attached to the control box.



Attention!

This mark reminds you to be more careful!

1.3.2 Sign and Labels

Table 1-1: Label Description

Label	Description
<p>超溫時，保護裝置動作；解除故障後，按藍色鍵復位並合上開關，重新通電運行。 Protection device activates when overheat occurs; after faults are discharged, press blue key to reset and turn on the switch to restart operation.</p> <p>超溫保護裝置 Overheat protection device</p>	<p>Protection device activates when overheat occurs; After faults are discharged, press blue key to reset and turn on the switch to restart.</p>

1.4 Exemption Clause


The following statements clarify the responsibilities and regulations born by any buyer or user who purchases products and accessories from Shini (including employees and agents).

Shini is exempted from liability for any costs, fees, claims and losses caused by reasons below:

1. Any careless or man-made installations, operation and maintenances upon machines without referring to the Manual prior to machine using.
2. Any incidents beyond human reasonable controls, which include man-made vicious or deliberate damages or abnormal power, and machine faults caused by irresistible natural disasters including fire, flood, storm and earthquake.
3. Any operational actions that are not authorized by Shini upon machine, including adding or replacing accessories, dismantling, delivering or repairing.
4. Employing consumables or oil media that are not appointed by Shini.

2. Structure Characteristics and Working Principle

2.1 Working Principle



Note: The drying temperature will be decreased in the heat insulation mode.

Picture 2-1 Working principle

3. Installation and Debugging

3.1 Power Connection


- 1) Make sure the voltage and frequency of the power source comply with those indicated on the manufacturer nameplate that attached to the machine.
- 2) Power cable and earth connection should conform to your local regulations.
- 3) Use independent electrical wires and power switch. Diameter of electrical wire should not be less than those used in the control box.
- 4) The power cable connection terminals should be tightened securely.
- 5) The machine requires 3-phase 4-wire power source, connect the power lead (L1, L2, L3) to the live wires, and the earth (PE) to the ground.
- 6) Power supply requirements:
Main power voltage: +/- 5%
Main power frequency: +/- 2%
- 7) ***Please refer to the circuit diagram of each model for specific power access specifications.***

Note: Keep 2m distance between the machine and flammable materials.

Note: Before connecting the power, turn the main power switch to "OFF" state, and the heater switch on dryer's control box to "OFF" state.





4. Operation Guide

4.1 Control Panel



Picture 4-1: Control Panel

Table4-1: Control Panel


ICONS	Name	Use
 20%	Heating ICONS	Represents the percentage of the current electric heating operating power, with a maximum value of "100" and a minimum value of "0". The current value is 20%, indicating that the power of the electric heating operation is 20% of the maximum power
 10%	Fan Running icon	Represents the percentage of the current fan operating power. The maximum value is "100" and the minimum value is "0". If the current value is 10%, it indicates that the fan is running at 10% of the maximum power
	Lock icon	Lit: Set temperature lock, cannot be modified under the main screen Off: Set temperature lock, can be quickly modified in the main screen
	Appointment timing icon	On: The reservation timing function is enabled Off: The reservation timing function is disabled

	Heat Preservation Mode icon	Lit: The unit is in Heat preservation mode Off: The unit is not in Heat preservation mode
	Self-setting icon	Lit: PID parameter self-tuning is on Off: PID parameter self-tuning is off
	Status indicator	Steady yellow: Stop/In stopping Steady green: In operation Flickering red: Fault alarm
	On/Off button	On/off button
	Menu button	Enter the user menu
	Set button	Set key
	Up button	Add value, select parameter up
	Down button	Reduce the value and select the parameter down

4.2 Common Interface

4.2.1 Startup delay screen

When the device is powered on, the system has a 7-second delay. After the countdown is over, the system automatically enters the "home screen".




Picture 4-2: Startup delay screen

4.2.2 Home screen

All startups are performed on the "Main operation interface". The corresponding icon indicates the relevant status. If the drying temperature now is 20 ° C and the drying temperature is set to 90 ° C (During operation, the blower and heating are


on, the timing function is enabled, and the temperature lock is enabled), the "main operation interface" will be displayed as follows:



Picture 4-3: Home screen

4.2.2.1 Quickly modify the set temperature under the main interface


If the user parameter [lock temperature] is set to "no", the set temperature can be directly modified under the main interface, the operation is as follows:




Note: You can also modify the set temperature in the user parameter.

4.2.2.2 Check related information on the main screen


1) The control mode is: Recipe mode:



2) The control mode is: Self-adaption mode:




4.2.2.3 The timing time is displayed on the main screen



Note: If there is no timed startup, the time is displayed 00:00.


4.2.2.4 ECO Mode

After the first start-up and the drying time, when the air exhaust set temperature > the actual temperature, and the anti-excessive drying time (default 30 minutes) is over, the unit will enter the ECO mode. The actual drying temperature decreases and the temperature is determined by the cooling deviation (default 20 °C); When the actual air exhaust temperature < the set temperature, the unit exits the ECO mode. To enter the ECO mode again, it only needs the actual air exhaust temperature > the set temperature and it lasts the anti-excessive drying time.



4.2.3 Fault screen


When the unit fails, it will automatically enter the fault interface, and the corresponding fault icon will be displayed. If the current drying temperature PV value is 20.0°C, the fault interface will be displayed as follows:



Picture 4-4: Fault screen


4.2.3.1 Fault query/reset interface

When the fault occurs, the alarm interface will automatically pop up. The fault query and reset operation are as follows:




4.2.4 Delayed shutdown and standby interface

4.2.4.1 Delay stop interface



Note: In the case of delayed shutdown, the main interface and the delayed shutdown interface are alternately displayed every 2 seconds until the shutdown countdown is over.

4.2.4.2 Standby interface



Picture 4-5: Standby interface

Note: Enter the standby interface after the delayed shutdown ends.

4.3 User Menu


Press <Menu> key in the main interface to enter the user menu, the user menu parameters are as follows:

Table4-2: User Menu Parameter Table

Serial No.	Parameter Items	Parameter Function	Remarks
1	User settings	Set user parameters Set the shutdown time Set the boot time Communication settings Recipe settings	User Settings in the relevant parameter Settings, see the User Settings parameter table
2	Information inquiry	Check the PV value of the drying temperature Check information such as the PV value of the return air temperature	
3	Historical fault	You can query all faults that have occurred in the last 10 times	Press the <Set> key for 2s to clear the history of failures.
4	Time settings	Set the current time to include year/month/day/hour/minute/second/week	
5	Version information	Inquire about the software version currently in use	

4.4 User Parameter Operations

To modify the parameter, modify the exhaust air setting temperature in the user Settings in the user menu as an example. Refer to the user parameter setting table for the parameter number and meaning in the user menu. The specific configuration method is as follows.



4.5 Parameter Table

4.5.1 User Parameter Setting Table

Table4-3: User Parameter Setting Table

Serial No.	Items	Initial Value	Set Range	Units	Remarks
User parameters (public) :					
On the home screen, press the "Menu" key to enter the menu. Select User Settings in the menu bar and press the "Set" key to access. Select User parameters and press the "Set" key to enter. Press the "Up" or "Down" button to pollor modify the parameters, and press the "Set" button to modify or confirm, and press the "Menu" button to exit.					
1	Drying time	120	1-999	Mins.	
2	Set drying temperature	90	0.0 ~ 200.0	°C	
3	Set exhaust air temperature	60	0.0 ~ 200.0	°C	
4	Timing function	Disable	Disable/use		Disable: The reservation timing function is disabled. Enable: The reservation timing function is enabled.

5	Lock the temperature	no	Yes/No		No: The setting temperature can be quickly modified from the home screen. Yes: The set temperature can't be quickly modified on the home screen.
6	Self-tuning	Disabled	Disable/use		This parameter is displayed only when the machine is running
7	Multiple languages	Chinese	Chinese /English		
8	Control mode	Recipe Mode	Recipe mode/Adaptive mode		

Shutdown time parameters (public) :

On the home screen, press the "Menu" key to enter the menu. Select User Settings in the menu bar and press the "Set" key to access. Select the shutdown time and press the "Set" key to enter. Press the "Up" or "Down" to poll or modify parameters, press the "Set" button to modify or confirm the setting, and press the "Menu" button to exit.

1	Monday shutdown time:	00:00	00:00 to 23:59		(1) The time is set to 00:00, and the timed shutdown function is disabled.
2	Tuesday shutdown time:	00:00	00:00 to 23:59		
3	Wednesday shutdown time:	00:00	00:00 to 23:59		
4	Thursday shutdown time:	00:00	00:00 to 23:59		
5	Friday shutdown time:	00:00	00:00 to 23:59		

6	Saturday shutdown time:	00:00	00:00 to 23:59		
7	Sunday shutdown time:	00:00	00:00 to 23:59		

Boot time parameters (public) :

Press the "Menu" key from the home screen to enter the menu. Select User Settings in the menu bar and press the "Set" key to access. Select the boot time and press the "Set" key to enter. Press the "Up" or "Down" button to poll or modify parameters, press the "Set" button to modify or confirm, and press the "Menu" button to exit.

1	Monday start time:	00:00	00:00 to 23:59		(1) The time is set to 00:00, and the timed power-on function is disabled.
2	Tuesday boot time:	00:00	00:00 to 23:59		
3	Wednesday boot time:	00:00	00:00 to 23:59		
4	Thursday boot time:	00:00	00:00 to 23:59		
5	Friday boot time:	00:00	00:00 to 23:59		
6	Saturday boot time:	00:00	00:00 to 23:59		
7	Sunday boot time:	00:00	00:00 to 23:59		

Communication setup parameters (public) :

Press the "Menu" key from the main interface to enter the menu. Select User Settings in the menu bar and press the "Set" key to access. Select Communication Settings and press "Set" to enter. Press the "Up" or "Down" button to poll or modify parameters, press the "Set" button to modify or confirm, and press the "Menu" button to exit.

1	Communication protocol	RTU	RTU		
2	Mailing address	1	1-99		
3	Baud rate	19.2 K.	4.8 K / 9.6 K / 19.2 K		

4	Check bit	No parity	No parity / Odd parity / Even parity		
5	Data length	8	8		
6	Stop bit	1	1 ~ 2		

4.5.2 Recipe list

Table4-4: Recipe List

Groups	Ingredients	Drying time (min)	Drying temperature (°C)	Exhaust air temperature (° C)
1	ABS	180	80	50
2	PP	120	90	45
3	PE	120	90	45
4	PS	120	80	45
5	PPS	240	140	65
6	PVC	120	70	40
7	PBT	240	120	60
8	PC	180	120	60
9	CAB	180	75	45
10	SAN	180	80	50
11	PEI	240	150	70
12	PEN	300	170	85
13	SB	120	80	50
14	PET	360	160	80
15	PETG	360	60	45
16	PI	180	120	60
17	PMMA	180	70	45
18	POM	180	95	50
19	CA	180	75	45
20	PPO	120	110	45
21	LCP	240	150	70
22	CP	180	75	45
23	PSU	240	120	60
24	PUR	180	90	50
25	TPE	180	105	55

26	PEEK	240	150	70
27	PES	240	160	80
28	PA	360	70	45

Note: Under the condition that the moisture content of materials meets the standard, decrease the exhaust air temperature appropriately can improve the energy-saving effect.

4.5.3 Trouble Table

This controller has various alarm functions. When a failure occurs, the alarm interface displays the current fault. The specific fault code meaning is shown in the following Table.

Table4-5: Trouble Table

Faults	Action
Flash error	<ol style="list-style-type: none"> 1. When the alarm occurs, the machine stops running. After troubleshooting, manually reset it. 2. Start detection after powering on, it occurs when the correct data can't be read in the flash.
Probe failure	<ol style="list-style-type: none"> 1. Stop heating, delay stop blower, trip output for 5 secs. After troubleshooting, automatic reset. 2. The test starts as soon as it is powered on.
High temperature	<p>When it alarms, stop heating, trip output 5 seconds, delay to stop the blower. After troubleshooting, manually reset.</p> <p>Start testing as soon as you power it on</p> <p>(1)【PV】-【SV】>【over temperature protection temperature】 and delay 2 seconds alarm.</p> <p>(2) After modifying the set temperature, only after the current temperature passes through the set temperature once, if the conditions in (1) are still met, the alarm will be given.</p>
Probe reverse connection	<ol style="list-style-type: none"> 1. Stop heating, delay stop the blower. After troubleshooting, automatically reset it. 2. The test starts after power-on.
Blower overload	<p>Stop the heat and the blower. Reset manually after dismissing the fault.</p> <p>Start testing as soon as you power it on.</p>

No battery.	<p>The machine continues to run when the alarm is given. After the fault is removed, the machine automatically resets.</p> <p>The alarm is detected only when the reservation timing function is enabled.</p> <p>Start detection as soon as it is powered on</p>
Pipe overheat	<p>Stop heating, delay stop blower, trip output 5 seconds. After troubleshooting, manually reset.</p> <p>2. Start testing immediately after power-on:</p>
Low temperature	<p>1. The machine continues to run when the alarm is given. After troubleshooting, the machine automatically resets.</p> <p>2. Detection after power on</p> <p>(1) $[SV] - [PV] > [\text{low temperature alarm}]$ and delay $[\text{low temperature reaction time}]$ alarm. When the temperature rises, automatic reset. If you want to prohibit, set $[\text{low temperature reaction time}] = 0$.</p> <p>(2) Wait until the current temperature passes through the set temperature once before starting to detect.</p>
Heating failure	<p>When it alarms, the machine continues to run and automatically resets after the fault is removed.</p> <p>Detection after starting up</p> <p>(1) After starting up, the temperature within the $[\text{heating alarm}]$ time, can't reach the $[SV] - 5^{\circ}\text{C}$ range, and it alarms. If you want to prohibit, set $[\text{heating alarm}] = 0$.</p> <p>(2) After the current temperature passes through the set temperature, the alarm is no longer detected.</p>
Return air probe fault	<p>1. Stop heating and delay stop blower. After troubleshooting, automatically reset.</p> <p>2. The test starts after power-on.</p>
Return air probe reversely connected.	<p>1. Stop heating and delay stop blower. After troubleshooting, automatically reset.</p> <p>2. The test starts after power-on.</p>
Inverter communication failure	<p>1. Stop the blower, stop heating. After troubleshooting, manually reset.</p> <p>2. Start the test as soon as it is powered on.</p>

5. Maintenance and Repair

5.1 Blower

- 1) Clean the blower regularly (especially the air inlet path) to remove the dust on surface.
- 2) Eliminate the blower's dirt regularly to avoid the blower damage.



Note: No need for regular inspection because all the electrical parts in the control unit are fixed tightly!